

Ax2

Bx4

Cx8

Dx1

Ex16

Fx4

Gx4

Hx1

M6x25

6. 3x40

1

Ax2
Gx4
Bx4
Cx8

A

G

x2

C

B

C

x4

2

Ex16

E

H

E

E

E

E

25mm

✓

E

40mm

✗

3

Dx1
Fx4

D

A

B

G

C

F

H

F

25mm


✗

F

40mm

✓

4



OGÓLNE ZASADY UŻYTKOWANIA PRODUKTÓW MODERNHOME

1. Stabilność mebla:
 - Zawsze upewnij się, że mebel stoi na stabilnym, równym podłożu.
 - Unikaj przeciążania mebla, co może doprowadzić do jego przewrócenia.
2. Ostrzeżenie dla dzieci:
 - Produkt nie jest zabawką. Trzymaj dzieci z dala od mebla podczas montażu.
 - W przypadku wysokich mebli (np. regałów, szaf) zaleca się użycie systemu mocowania do ściany, aby zapobiec przewróceniu się mebla.
3. Bezpieczeństwo użytkowania:
 - Nie wchodź na mebel ani nie stawaj na nim (jeśli nie jest do tego przeznaczony).
 - Unikaj używania mebla do celów innych niż przeznaczone.
 - Regularnie sprawdzaj stabilność i stan techniczny produktu. W przypadku uszkodzeń zaprzestań użytkowania.
4. Montaż i konserwacja:
 - Produkt należy montować zgodnie z załączoną instrukcją obsługi.
 - Wszystkie elementy montażowe muszą być prawidłowo dokręcone. Po zakończeniu montażu sprawdź stabilność mebla.
 - Do czyszczenia używaj łagodnych środków czyszczących. Unikaj substancji chemicznych mogących uszkodzić powierzchnię.
5. Przechowywanie i transport:
 - Unikaj długotrwałego narażania mebla na wilgoć, wysokie temperatury lub bezpośrednie działanie promieni słonecznych, które mogą uszkodzić powierzchnię.
 - W przypadku transportu zabezpiecz produkt przed uszkodzeniami mechanicznymi.
6. Zgodność z normami:
 - Produkt został przetestowany zgodnie z wymaganiami dotyczącymi bezpieczeństwa i jakości określonymi w obowiązujących przepisach.



GENERAL RULES FOR USING MODERNHOME PRODUCTS

1. Furniture stability:
 - Always make sure that the furniture is standing on a stable, even surface.
 - Avoid overloading the furniture, which may cause it to tip over.
2. Children's warning:
 - The product is not a toy. Keep children away from the furniture during assembly.
 - For tall furniture (e.g. shelves, wardrobes), it is recommended to use a wall attachment system to prevent the furniture from tipping over.
3. Safety of use:
 - Do not climb or stand on the furniture (if not intended for this purpose)
 - Avoid using the furniture for purposes other than its intended purpose.
 - Regularly check the stability and technical condition of the product. In the event of damage, discontinue use.
4. Assembly and maintenance:
 - The product must be assembled in accordance with the enclosed instruction manual.
 - All assembly elements must be properly tightened. Check the stability of the furniture after assembly.
 - Use mild cleaning agents for cleaning. Avoid chemicals that may damage the surface.
5. Storage and transport:
 - Avoid prolonged exposure to moisture, high temperatures or direct sunlight, which can damage the surface.
 - In the event of transport, protect the product from mechanical damage.
6. Compliance with standards:
 - The product has been tested in accordance with the safety and quality requirements specified in applicable regulations.



PRODUCENT:
MULTISTORE ECOTOYS Krystian Ślebioda
Sady, Logistyczna 31, 62-080 Tarnowo Podgórne

sklep@multistore.pl
b2b-multistore.eu

MADE IN CHINA